


COAX CABLE EXTENSION


RF CONNECTOR COUPLER SIDE (bb)



- 01 RP-SMA Male
- 03 SMA Male

RF CONNECTOR RADIO SIDE (cc)

- 01 RP-SMA Male
- 02 RP-SMA Female
- 03 SMA Male
- 04 SMA Female
- 07 N Male
- 08 N Female
- 09 TNC Male
- 10 TNC Female
- 11 BNC Male
- 12 BNC Female
- 13 MCX Male 90°
- 15 MMCX Male 90°
- 16 RP-SMA Male 90°
- 18 SMA Male 90°
- 19 SMB Male
- 21 RP-TNC Male
- 23 SMB Female
- 24 U.FL Female
- 29 N Female bulkehead



CONFIGURATION



PT B 01 03 - 06

a b c d

a - Coax cable type

- A RG316 (100 MHz - 3 GHz)
- B LMR-100A (100 MHz - 8 GHz)
- C I999 (100 MHz - 3 GHz)
- D LMR-240 (100 MHz - 8 GHz)
- G RG178 (100 MHz - 6 GHz, only for U.FL)

b - RF connector coupler side

see above

c - RF connector radio side

see above

d - Coax cable length

- 06 6" (15 cm)
- 12 12" (30 cm)
- 18 18" (45 cm)
- 24 24" (60 cm)
- 30 30" (75 cm)



SOLEXY srl

Via Enrico Fermi, 2
25015 Desenzano del Garda (BS) **Italy**
Phone (+39) 030 787.0.787
Email: info@solexy.net

SOLEXY USA, LLC

PO Box 628
West Chester, Ohio 45071 **USA**
Phone: (+1) 513.860.5465
Email: usa@solexy.net



www.solexy.net